

# Dribond Level Floor Tuff

## SELF LEVELLING FLOORING COMPOUND

### PACKAGING




### MIXING



### APPLICATION



### USES



### SUBSTRATES

CONCRETE FLOORS

### DESCRIPTION

A resin modified, fast setting cement based compound for use as a levelling compound and repair screed. Its smooth texture and high fluidity allow ease of placement, trowelling, feather edging and finish.

### USES

A high strength, hard wearing, chemical resistant, resin modified cement based floor levelling and repair compound for internal and external use. LEVEL FLOOR TUFF performs like a sheet of steel levelling internal or external concrete floors in warehouses, driveways, parking lots, walkways, balconies etc.

### FEATURES

- Feather edge to 15mm thick
- 100Mpa strength
- Water resistant – rapid set

### COVERAGE

Approximately 1.5 kg / m<sup>2</sup> per 1 mm thickness.

### PERFORMANCE DATA

	1 Day	7 Days	28 Days
<b>Compression Strength</b>	56.1Mpa	84.4Mpa	100Mpa
<b>Hardness</b>	54 (Shore D)	65 (Shore D)	68 (Brinnell)
<b>Adhesion to Substrate</b>	3 Mpa		

### Chemical Resistance

Resistant to petroleum solvents (i.e. petrol - diesel) strong alkali and weak acids (i.e. pH4).

### SURFACE PREPARATION

Surfaces must be firm and structurally sound, free from dirt, wax, oil, grease, paint, ponded water, laitance and all contaminants. Contaminated/ultra smooth floors will need to be mechanically abraded or dustless shot blasted to roughen and abrade the surface. When in doubt about the surface preparation or priming, a 1m<sup>2</sup> test area is recommended. A thorough repeated sweeping with a hard broom, followed by mopping with clean water to remove all contaminants is essential.

### PRIMING

**Internal helicoptered or steel trowelled finish concrete:** Prime with SUPER PRIME applied with a hard brush, working well into the surface.

**External concrete, terrazzo, ceramic tile or non porous surfaces:** Prime with PRIMAX with a hard broom, working well into the surface.

**Damp concrete /difficult to adhere to substrates:** Apply EPECRETE with a brush or roller to damproof the floor and improve adhesion.

## MIXING

Place 4.2 litres of drinkable water in a mixing container and gradually add 20kg of level floor using a slow speed drill. **DO NOT hand mix or add in excess of 4.4 litres of water as this causes lumps, cracking, product separation and leaves a yellow layer on the surface indicating over watering.** Mix for 1-2 minutes and place the product immediately – the levelling properties reduce in effectiveness after 10 minutes making levelling and finishing more difficult. Use the mixture within 15 minutes. Discard unused material after this time.

LEVEL FLOOR TUFF can be applied feather edged to 15mm. Over 8mm add up to 30% dried washed sharp coarse sand or fine aggregate, depending on the thickness required.

## APPLICATION

Pour the mixed levelling compound onto the prepared floor and spread with a levelling compound spreader or large metal trowel, keeping the trowel slightly inclined to obtain the desired thickness.

Spread the material to the desired thickness in one application. Use sufficient material to cover high points with 2-3mm thickness. The levelling compound smoothes itself during the first 10 minutes. Apply when the temperature is 5-30°C, do not apply in direct sunlight as this can cause the surface to crack.

If required, an additional layer or finish coat over the aggregate mix can be applied after the surface is primed with PRIMAX but the layer should not exceed 50% of the previous layer.

The levelling compound can be walked on in 2-4 hours and put into use the next day, (12 hours @ 20°C @ 50% RH).

## SURFACE MOISTURE

When adhering floor coverings, check surface moisture with a moisture meter if in doubt about moisture content.

## CURING

Normally curing is not necessary but when applying thin coats (under 3mm) in direct sunlight, warm temperatures and low humidity, keep the surface moist or covered with plastic for 24 hours after the surface can be walked on.

## SAFETY PRECAUTIONS

Non-toxic but contains cement which contains silica. Wear gloves and appropriate respirator. For further information refer to Material Safety Data Sheet.



- **ADELAIDE** 467 - 469 SOUTH RD REGENCY PARK 5010 PH: (08) 8346 8013 FAX: (08) 8340 2052
- **BRISBANE** 45 COULSON ST WACOL 4076 PH: (07) 3271 2944 FAX: (07) 3271 3892
- **MELBOURNE** 11 GABRIELLE CT BAYSWATER NORTH 3153 PH: (03) 9761 4711 FAX: (03) 9761 4748
- **PERTH** 11 COLLIE RD WELSHPOOL 6106 PH: (08) 9356 9999 FAX: (08) 9356 9955
- **SYDNEY** 31 NEWTON RD WETHERILL PARK 2164 PH: (02) 9756 3533 FAX: (02) 9756 3534
- **AUCKLAND** 16 CARPENTER RD EAST TAMAKI PH: (09) 273 5444 FAX: 0800 266 236
- **KUALA LUMPUR** LOT 2 JALAN KECAPI 33/2 ELITE INDUSTRIAL ESTATE OFF JALAN BUKIT KEMUNING 40000 SHAH ALAM PH: (603) 5122 2522 FAX: (603) 5122 2526